


# INSTALLATION INSTRUCTIONS

Model  
FT/FS-2



When ordering replacement parts, please provide the following information:

1. Part Number
2. Part Name
3. Model Number
4. Specify design (if any)

To install your Shower Enclosure you will need the following:

- Level
- 1/8" and 9/64" Drill Bits
- (Tile) 3/16" Masonry Bit
- Phillips Screwdriver
- Sealant
- Hack Saw

#	Description	Qty	Part #	Picture
1	Roller Wheel Assbly	4	ZA-99	
2	Curb Vinyl	1	ZV-963	
3	Glazing Vinyl		ZV-983	
4	Bottom Rail	2	ZTE-7202	
5	Top Rail	2	ZD-7208	
6	Side Rail	4	ZTE-7201	
7	Framed Knob	1	ZTE-7204	
8	Curb	1	ZTE-7222	
9	Wall Jamb	2	ZTE-7203	
10	Screw Anchor	6	ZV-935	
11	#8x1 1/4 Pan Head Screw	6		
12	Jamb Bumper	2	ZV-927	
13	Header	1	ZTE-7200	
14	Towel Bar Bracket	2	ZTE-7206	
15	Towel Bar	1	ZTE-7205	
16	Button Knob	1	ZFTE BKCIR	
17	Center Guide	1	ZV-972	
18	#6x1 1/4 PH SMS	8		
19	#6/32x1 PH Truss Head	3		
20	#6x3/8 Machine Screw	5		
21	180 Jamb Post	4	ZTE-7218	
22	Buttress Curb	2	ZD-1014	
23	Vertical Wedge Vinyl	8	ZV-909	
24	#8x1 Pan Head Screw	6		
25	Glass Setting Block	4	ZV-902	

Arizona Corporate Office  
2801 W. Indian School Rd  
Phoenix, AZ 85017  
800-255-1901 PH  
602-447-8208 FAX

Florida  
8100-1 Westside Industrial Dr  
Jacksonville, FL 32219  
855-695-8899 PH  
904-786-9025 FAX

Illinois  
2601 Bond St #1  
University Park, IL 60484  
800-861-6120 PH  
708-235-0729 FAX

Oregon  
2057 Lars Way  
Medford, OR 97501  
866-773-7905 PH  
541-773-7909 FAX

Colorado  
3871 Revere Street  
Denver, CO 80239  
866-574-1766 PH  
303-574-1775 FAX

Utah  
2594 S. 3600 West Suite A  
West Valley City, UT 84119  
877-402-5007 PH  
801-972-3111 FAX

# ARIZONA SHOWER DOOR

## Tools you will need for this install





- ✓ Exploded View drawing of shower door
- ✓ 3/16" Masonry drill bit (use 9/64" drill bit for fiberglass)
- ✓ 1/8" drill bit
- ✓ Drill
- ✓ 4' Level
- ✓ Saw (Electric Chop saw or Hacksaw)
- ✓ Side cutting pliers
- ✓ #2 Phillips drill bit
- ✓ #2 Phillips screwdriver
- ✓ Tape Measure
- ✓ Pencil or Pen
- ✓ Caulking Gun
- ✓ 1-Tube of 100% Clear Silicone (no latex!)
- ✓ Vacuum Cleaner or Brush for clean up
- ✓ Glass Cleaner and Paper Towels
- ✓ Rubber Mallet
- ✓ File

## Installation Instructions for

# Model FT-2 & FS-2

**Note:** These instructions will refer to the item #'s in the Exploded View drawing. For example, #1, #2, #3 etc... Please read through **all** of the instructions to get an over-view **before** you install the door.





**1)** Typical placement for the shower door is in the center of the curb or tub ledge. Make marks on the curb/tub ledge to represent where the **outside** of the shower door will sit. These marks should correspond with the dimensions the shower door was ordered to. **Note: The glass pocket in the ZTE7218 is offset to the outside.** Place the ZTE-7218 Wall Jambs (item #17 in exploded view) against the wall of the shower on each side and on top of the ledge or curb aligning the outside edge of the jambs to the outside marks that were previously made **(A)**. **(Note:** Holes may need to be drilled in ZTE-7218 glass pocket) Use a level to position the jamb plumb, then mark the installation holes with a pen or pencil **(B)**. **NOTE:** If you are installing on fiberglass you might have to file a radius on the backside of your jambs where the ledge/curb and the wall meet.



**2)** Now drill the 6 holes with a 3/16" masonry bit (9/64" regular bit for fiberglass, & without anchors). Then insert the 6)-ZV935 screw anchors (#2) in the holes. Fasten the ZTE-7218 wall jambs in place using the #8X1-1/4 Phillips Pan Head screws provided (#13) **(C)**.

**3)** Cut the ZD-1014 Buttrass Curbs (#18) 1/2" wider than the inline panels of glass. These are the horizontal channels that hold the fixed panel **(D)**. Put a dab of silicone in the inside corner of the ZTE-7218 Wall Jamb then insert the ZD-1014 and push over into the ZTE-7218 aligning it to the outside marks that were made in step 1 **(E)**. **Note:** The ZD-1014 will be secured after the final step of running silicone at the end of the install. When the silicone cures then the ZD-1014 will be solid.

**4)** Cut two setting blocks at 1/4" tall and insert them down into the ZD-1014 for the glass to sit on. Then place the fixed panel into the wall jamb and down into the bottom channel until the bottom channel extends past the glass approximately 1/4" **(F)**. Attach the ZTE-7203 and the ZTE-7218 by screwing the two pieces together using the #8X1-1/4 Phillips Pan Head screws provided (#3) **(Note:** This may be a 1" screw depending on the model). Place the 180° Post which consists of a ZTE-7203 Wall Jamb (#1) and a ZTE-7218 180° Jamb Post (#17) attached together, over the edge of the glass **(G)**. Insert the ZV909 Wedge Vinyl (#19) into








the vertical jambs on both sides. A block of wood will help push the vinyl in. Wet the vinyl slightly with water to ease install. The flat side goes against the glass. Make sure the posts are plumb **(H)**. Repeat this process for the other panel on the opposite side.

**5)** Measure the distance wall to wall above the jambs for the ZTE-7200 Header (#8) dimension. Cut to size. Place the header over and down on to the jambs **(I)**.

**6)** Measure for the ZTE-7222 (#6) by measuring the distance between the inside of the two ZTE-7203 Jambs then cut the ZTE-7222 (#6) to that dimension minus a 1/16" to 1/8" **(J)**. Run some silicone on the inside of the ZTE-7203's where they meet the curb/tub ledge. Then run a bead along the underneath of the ZTE-7222 Curb **(K)**. Slide the curb down between the wall jambs and onto the tub/shower. Secure it with two of the #6X3/8" Pan Head Screws (#13) provided by drilling with a 1/8" drill bit through the outside legs of the ZTE-7203 wall jambs at the bottom, into the face of the curb and inserting the screws **(L)**.


**7)** Plumb the 180° Jamb/Posts (#1+#17) and attach the header to the Jambs and Posts from the inside using #6 x 3/8" Phil Pan Head Screws (#13). Attach the ZV975 Bumpers (#4) using the #6/32X1/2 Machine screw (#5) keeping in mind




that the inside panel will be on the showerhead side of the shower **(M)**.

**8)** Setting of the glass. The inside panel will be set first. This will be done as you stand on the **outside** of the shower. Grip one of the panels on each side so that the rollers are facing **away** from you. Lift the panel so that the bottom edge of the glass clears the top of the ZTE-7222 Curb as you lower it into the shower. **Do not set the glass down on its edge. Be very careful to not hit the edge on anything.** Continue lowering the panel down until the top rollers can be guided up into the inside roller track of the header. Lift up glass then slowly lower the rollers into the inside roller track and let the panel hang in its vertical position. The outside panel will be installed the same way. Make sure the rollers are facing **toward** you. A helper would be valuable at this point to hold the inside panel on an angle toward the inside so the outside panel can be lowered and positioned to be installed into the outside roller track. The inside panel will be positioned at the showerhead side of the shower while the outside panel will be positioned opposite the showerhead. This is to ensure that no water escapes through the overlap **(N)**.


**9)** Adjust Rollers. The roller wheels are mounted to angled slots in the top rail on the glass. Lowering the roller in the slot raises the glass. Raising the roller in the slot lowers the glass. Start out with the rollers mounted in the middle of the angled slot. If the panel needs to be adjusted you can remove the panel, adjust with a screwdriver then, reset the panel. This might be done one or two times until you




**N**




achieve proper alignment. The end result should be that the vertical edge of the panel is parallel to your wall jamb to achieve maximum coverage **(O)**.



**10)** Attach the ZV972 Center Guide (#17). Position the guide in the center of the overlap of the panels. When the doors are in a closed position the center guide should be centered in the overlap of the panels. Attach the guide in place by drilling with a 1/8" drill bit through the inside leg into the curb (from the inside of the shower) then running a #6X3/8 screw into the hole **(P)**.



**11)** Attach the ZTE-7204 Framed Knob (#7) by inserting the mounting screw (#19) through frame and into the knob and tighten with allen wrench provided **(Q)**.



**12)** Attach one ZTE-7205 (#14) Towel Bar Bracket using one of the two #6/32x3/8" PH Truss Head Screw (#19). Place the ZTE-7205 Towel Bar (#15) into the other ZTE-7206 Towel Bar Bracket then slip the other end of the towel bar into the previously mounted bracket. Hold into place while you run the other screw through the frame and into the bracket **(Q)**.

**13)** Run a bead of silicone on the gap between the metal and the shower surface inside and out. Fill all joints and gaps where metal meets metal and fill with a fine bead. Run a bead also in the gap where the ZD-1014 and the glass meet **(R)**.

**14)** Insert ZVHPBLK Rail Plug into open hole on frame rail **(S)**.

